Thank you for using this product.

For safety reasons, please read this manual carefully before installation and operation, and keep it for future reference.
Product changes due to technical improvements are subject to change without prior notice.
The changes will be directly incorporated into the new manual.

(This manual is for reference only, please refer to the actual head unit)

Precautions

Read these instructions in detail before installing and operating the equipment, and it is recommended that this head unit is installed by a car audio professional. This equipment is compatible for vehicles with 12V power system (there must be a grounding wire). Please do not install this equipment directly on a 24V truck or other high-voltage-system vehicles.
Under no professional guidance, please do not change the fuse or use improper fuse, otherwise it will cause damage and fire hazard.
The touch-screen of this product adopts delicate electronic structure. Do not operate the touch-screen with sharp objects or excessive force to avoid damage.
In order to avoid accidents and violation of traffic regulation, drivers shall not watch video and/or excessively operate the head unit while driving.
Shall problems occur, please return this product to authorized dealer. Do not disassemble and repair this equipment to avoid damage or other accidents. Please consult authorized personnel for details.
Prevent this head unit from being exposed to moisture and water to avoid electric shock, damage and fire.

Note: To prevent short circuit, please turn off the car and disconnect the car battery before installation.

Functional Operation

Panel Button Function

1. Short press the front defogger button on the panel to turn on the front defogger function of the air conditioner.
2. Short press the HOME button on the panel to enter the head unit (HU) main page.
3. Short press the power button on the panel to put the unit into standby.
4. Short press volume + button to increase the volume. Long press to gain maximum volume
5. Short press volume – button to decrease the volume. Long press to mute.

Audio Control

Short press [VOL+] button. HU volume increases by 1. Long press [VOL+] button. HU volume continues to increase by 1 until the system volume reaches maximum.

Short press [VOL-] button. HU volume decreases by 1. Long press [VOL-] button. HU volume continues to decrease by 1 until the system volume reaches minimum.

Short press [SRC] button. Head unit (HU) will switch between active sources. Long press [SRC] button, HU will not respond.

Short press [Next] button. USB music / BT music / AUX music plays the next song. Radio searches to higher frequency band, will stop at nearest active radio station and plays that station.

Short press [Previous] button. USB music / BT music / AUX music plays the previous song. Radio searches to lower frequency band and will stop at nearest active radio station and plays that station.

[Answer] When the HU Bluetooth is connected to phone, short press the button to enter the Bluetooth call page or to answer the incoming call. When the HU Bluetooth is not connected, short press the answer button to enter the Bluetooth settings page. Long press of the button is invalid.

Hang up /mute
When the HU Bluetooth is connected to phone, short press the button to hang up on current phone-call. In other cases, short press the button, the sound source is muted; short press again to cancel the mute. Long press of the button is invalid.

Boot Animation

When the car starts ACC, the head unit starts synchronously with the car, and the page displays the boot LOGO, and then jumps to the main page.

When the car turns off ACC, the head unit will shut down automatically after 3 minutes.

When the car turns off ACC, press the power button or lock the door about 1 minutes to shut down the head unit.

Main Page

After entering the main page, you can select **USB, Wuling Link, FM** in the shortcut entry to perform the function operation.



Main Page

Icon

After entering the main page, you can select **Phone, Settings, File** on the icon bar to perform the corresponding function operation.

Click **Phone** to enter the dial page.

Click **Settings** to enter the settings page.

Click **File** to enter Video, Picture, and TXT explorer.

Main Page

Swipe right on the icon bar to enter the second page.

Click **Tire-pressure** to enter the tire pressure monitoring page.

Click **Air Conditioner** to enter the air conditioner page.

Click **User Manual** to enter the user manual page.

Main Page

20°C Click on lower menu bar
to enter the temperature adjustment page.

AUTO Click on lower menu bar
to enter the air conditioning control interface.

OFF Click on lower menu bar
to turn off the air conditioner,
if the air conditioner is currently turned on.

Click on lower menu bar
to enter air blower modes page.

Click on lower menu bar
to enter the fan speed adjustment page.

360° Click on lower menu bar
to enter 360° camera page.



Entertainment

Music

Music | Bluetooth Music | AUX

Click **HU will enter the music interface.**

Click **to play next song.**

Click **to play previous song.**

Click **to open current playlist.**

Click **to add current song to favorite list.**

Click **to set playback modes.**

Click **to alternately pause and resume music.**

Bluetooth

Click **"Bluetooth Music"**, HU will enter the Bluetooth music interface.

Music | Bluetooth Music | AUX

Click **to play next song.**

Click to play previous song.

Click to alternately play and pause current song.

Aux

Click **”AUX”**, HU will enter the AUX page, and play the AUX audio source.



Phone



Click , HU will enter Bluetooth phone interface.

Click **“Recents”** to enter the phone call record page, you can select a call record to make a call.

Click **“Keypad”** to manually dial the number.

Click **“Contacts”** to enter the contacts page. If address book is not synced, it will be displayed as “None”.

Phone

When Bluetooth call comes in, you can choose to answer the call or hang up the phone on the head unit.

Hang up the phone

Answer the call

Wuling Link



Click , to enter Wuling Link function.

If the Wuling Link connection is abnormal, HU will display "No device or USB debug mode is off!"

Before the HU uses the Wuling Link function, user needs to complete the following steps:

a. Turn on the HU Bluetooth function.

b. Activate the Bluetooth on the mobile phone, and make sure to successfully connect the phone to the HU.

c. The mobile phone only supports the following APP software: Facebook, Line, Youtube, Google search, Gmail, Instagram, google map, JOOX, whatsapp, spotify.

d. Connect the HU and mobile phone with the USB data cable. When the connection is successful, a message "Whether to start USB debugging" will pop up. Click "Sure".

e. If Wuling Link is not already installed on the phone, HU will push the default version into the connected phone.

f. Multimedia does not support JOOX and other apps that come with karaoke function.

Wuling Link

If Wuling Link is connected normally, HU enter the Wuling Link interface.
Wuling Link can connect your HU to the Android phone and operate the phone on the HMI interface. The sound is transmitted via Bluetooth.

* Note: See appendix for detailed link instructions and compatibility lists.

Radio

FM Radio

Click , HU will enter the radio interface.
Enter the radio page to switch between bands, including “AM”, “FM”

Click ,The entire FM audio creation station can be and the stations with strong signals are automatically stored.

Click ,to tune to 50 KHz higher frequency.

Click ,to tune to 50 KHz lower frequency.

Click ,to automatically search next station in higher frequency. The search will stop at that active station.

Click ,to automatically search next station in lower frequency. The search will stop at that active station.

Click ,to save current station to Favorite list.

AM Radio



Enter the AM page

Click ,The entire AM audio creation station can be searched and the station with strong signal is automatically stored.

Click ,to tune to 9 KHz higher frequency.

Click ,to tune to 9KHz lower frequency.

Click ,to automatically search next station in higher frequency. The search will stop at that active station.

Click ,to automatically search next station in lower frequency. The search will stop at that active station.

Click ,to save current station to Favorite list.



Click , to enter air conditioning interface.

Click [AUTO], the air conditioner will automatically adjust the temperature, mode, air volume, internal and external circulation and A/C according to the cabin temperature.
Click [AC] to turn on manual temperature and fan speed control.

Click the / button or slide the white square to increase/ decrease the temperature.

Click the / button or slide the white square to increase/ decrease the fan speed.

Airflow directions are divided into:
Head and feet, Head only, Feet only, Feet and front defogger, Front defogger.

Click icons to switch between modes.

Click [AC OFF] to turn off the air conditioner.

Personal Setting

Setting



Click , HU enters the setting interface.

Bluetooth
When entering Bluetooth for the first time, the car has no pairing history, and the mobile phone and the car Bluetooth are required to be paired.

When the car has a pairing history, select the Bluetooth name of the mobile phone to be connected to “connect”.

Slide right to turn on car Bluetooth.

Slide llide left to invoke the remove icon, remove it from “My Devices” list, and display it in the “Other Devices” list.

Equalizer

Click **Equalizer** button to enter the Equalizer page. In this page, you can adjust the settings of “Tone”, “Loudness”, and “Speed volume compensation”.

Adjust the Bass, Mid-range, and Treble equalization by sliding the bars to left or right.

Loudness is enabled by default. Slide [On] / [Off] to turn on/off the loudness.

Equalizer



By dragging the white indicator in the car display, adjust the “left and right” sound balance, “front and rear” sound balance and other settings. Click the [reset] button and the white indicator will return to the middle position.

Volume



Click the volume button to enter the volume setting page. In this page, you can adjust the media volume and phone volume.

Display

Click **Display** button to enter the brightness setting page. In this page, you can choose to display the brightness mode [Day] / [Night] / [Auto]. When the [Day] / [Night] mode is selected, the brightness value can be adjusted by the slider.

Display

Language



Click **Language** button to enter the language setting page. In the language setting page, you can switch between English/Indonesian.

Language

Date & Time

Click **Date & Time** button to enter the time setting page.

In this page, you can select the [12 hours] / [24 hours] format.

Click **Time Zone** to select the time domain, and bring out the corresponding date and time according to the time domain. After clicking [Set Date] / [Set time], the date/time setting appears. Swipe up and down to set the “Year/Month/Day” or “Hour/Minute” setting.

Date & Time

Vehicle Setting



Vehicle Setting



Click **Vehicle setting** button to enter the vehicle settings page, Including **“CAR WINDOW”,”CAR LOCK”, “CAR LIGHTS”, “OTHERS”.**

Vehicle Setting



CAR WINDOW
Remote Window Roll Down: Select ON / OFF, If this function is on, when car key unlock button is pressed long, the windows and sunroof automatically opens.

Vehicle Setting



Car Lock
Door Remote Unlock :
Select **All Doors/Driver-Side Door** default All Doors.

Stalling Auto Unlock :
Select **All Doors/Driver-Side Door / Close**, default All Doors.

Door Auto Lock:
Select **ON / OFF**, if this setting is on, all doors will automatically lock when the vehicle speed exceeds 10km/h.

Vehicle Setting



CAR LIGHT
Lane Change:
You can select **On / Off**. When turned on, the turn signal will flash three times and then turns off.

Illuminated Entry:
You can select **10MIN / 20MIN / 30MIN**, the default is 10MIN.

Walk Me Home:
You can select **On / Off** to enable this function, you can select the duration **30S / 50S / 75S.**

Find My Car:
You can select **flash + whistle / flash**, the default flash.

Vehicle Setting



CAR OTHER
Wiper Maintence:
Select **On / Off**, the default is on.

Auto OSRVM:
You can select **On / Off**, the default is on, and the rear view mirror is automatically folded when engine is turned off and doors are locked.

Skin Setting



SKIN SETTING
Click **Skin Setting** button to enter the Skin Setting page.

You can select **Blue Grey / Dark Blue** to switch the system background color

USB Storage

USB STORAGE
Click **USB Storage** to enter USB Storage page.

It displays USB capacity and memory usage of Video, Picture, Music, and Other files.

Factory Reset



FACTORY RESET
Click **Factory Reset** to enter Factory Reset page.

Click **OK** to restore the factory settings.

ABOUT Wuling



ABOUT Wuling
Click **ABOUT Wuling** to enter the version information page.

The version information includes HU-SOC ,HU-MCU and HU-HW.

File



FILE
Click the **File** buttonin the icon to enter the file page. File includes Video.

Picture, TXT.

Switch to view the Video/Picture/TXT list information by clicking the **Video/Picture/TXT** button.

Video/Picture/TXT is shown in abbreviated form, swipe left and right to see more information.

Tire Pressure

TIRE PRESSURE

Click the **Tire Pressure** to enter the tire pressure page. It displays pressure (in Bar) and temperature (in degree Celsius) of each tire. When the tire pressure/temperature is abnormal, red color is displayed.

User Manual



USER MANUAL

Click **User Manual** to enter the User Manual page.

Swipe up and down to view the user manual.

360 View

Click the **360View** in the lower menu bar to enter the 360 View page.

Front/rear view is displayed on upper-half of the screen. Left/right view is displayed on lower left, and the composite (surround) view is displayed on lower right.

Click to switch the view of front/rear side;

Click on lower left screen to switch the view of left/right side;

Click on the upper/lower area of the car on the lower right screen, the top-view display will switch to the corresponding front/rear view;

Click on the left/right area of the car on the lower right screen, and the lower left screen will switch to the corresponding left/right view.

Click to exit the 360 View page.

The reversing camera display is the same as 360 View, and is activated when the car is in R (reverse) gear. It automatically turns off when the shifter is no longer in R position.